# VME Intensity Monitor - Task #13919

# Fix scaling for ring pick MPS thresholds

09/23/2016 10:46 AM - John Diamond

Status:	Assigned	Start date:	09/23/2016	
Priority:	Normal	Due date:		
Assignee:	John Diamond	% Done:	80%	
Category:	MPS	Estimated time:	8.00 hours	
Target version:		Spent time:	10.00 hours	

### Description

The PXIE ring pickup MPS thresholds never made sense because they are set in ADC integrated counts. Ning has provided a method for scaling to amps -

# History

#### #1 - 09/23/2016 10:50 AM - John Diamond

The above formula scales to E10 not Amps.

## #2 - 09/23/2016 11:03 AM - John Diamond

Gate Width should be the gate width as read from the digitizer in raw ADC clock ticks.

#### #3 - 09/23/2016 12:56 PM - John Diamond

I came up with the inverse function as -

```
Threshold_Setting = (C5 * GW) * (C4 + C1 * C3^( (C2 * I_THR) / GW))
```

## #4 - 09/27/2016 09:13 PM - John Diamond

- % Done changed from 0 to 80

Implemented support for scaling the MPS upper/lower thresholds inside the front end. Created a CLI command for specifying scaling parameters:

vmeintMPSThresholdScaleFilterSet deviceId, scaleMethodStr, c1Str, c2Str, c3Ctr, c4Str, c5Str, c6Str

- deviceId is the intensity device ID
- scaleMethodStr specifies what kind of scaling should be done. The default method is "linear". For the PXIE ring pickups this parameter should be "pxie\_ring\_pickup".
- c1Str .. c6Str are the scaling coefficients (these are floating-point parameters, they must be passed as strings e.g. "2.0")

  linear: C1 \* x / C2 + C3

10/18/2020 1/2

## #5 - 09/27/2016 10:47 PM - John Diamond

Add a line of output to vmeintShow to display the MPS threshold scaling information:

10/18/2020 2/2